Systen Digital Control Unit (DDC)

Maintenance Task Description	Frequency	Skill	Time	Special	Parts	Specific
		Level	Hours	Tools		Safety
				Reqd.		Instructions
Check all manual overrides to verify that each is in the "auto"	M	٦	0.25	none	none	1,2,3
position.						
Check the DDC system clock/calendar function as to correct	Σ	٦	0.25	none	euou	1,2,3
time and date.						
Check the DDC system event log and verify at each point type	Σ		0.25	none	none	1,2,3
that input/output points are operating correctly within its range.						
Check the batteries on the DPU and replace if found to be weak,	⋖	7	0.25	volt	replacement	1,2,3
or if recommended by the manufacturer.				meter	battery	
Check and modify the holiday and daylight savings time clock	⋖	7	0.25	none	none	1,2,3
schedule.						
Check the operation of the system digital outputs using the	⋖	٦	0.25	none	auou	1,2,3
manual override switches located on the DDC panels.						

* Frequency Legend	Daily	Weekly	Monthly	Quarterly	Semi-annually	Annually
* Frequen	۵	Μ	Σ	Ø	SA	A

Safety instructions to observe when working with this equipment are as follows:

Electrical power to the MBU, Terminal Units, damper and valve actuators is 120 Volts. Disconnect the power supply to these items. 1 Caution:

When working on electrical components do not use metal ladders. 2 Caution: 3 Caution:

When using a step ladder never stand on the top step of the ladder.