System: Global Controller (GC)

Maintenance Task Description	Frequency	Skill Level	Time Hours
	*	**	***
Check all manual overrides to verify that each is in the "auto" position.	М	J	0.25
Check the DDC system clock/calendar function as to correct time and			
date.	М	J	0.25
Check the DDC system event log and verify at each point type that			
input/output points are operating correctly within its range.	М	J	0.25
Check the batteries on the CPU and the DCP's and replace if found to be	е		
weak, or if recommended by the manufacturer.	Α	J	0.25
		-	
Check and modify the holiday and daylight savings time clock schedule.	Α	J	0.25
Check the operation of the system digital outputs using the manual			
override switches located on the DDC panels.	Α	J	0.25

* Frequency Legend		
D	Daily	
W	Weekly	
M	Monthly	
Q	Quarterly	
SA	Semi-Annually	
А	Annually	

	** Skill Level Legend
0	Unskilled Laborer
Α	Apprentice Mechanic
J	Journeyman Mechanic
М	Master Mechanic
FT	Factory Trained Tech.

*** The time indicated is for the required to service one unit